

PRESS PAR
USE FN△ OR FN▽ UNTIL 1-INP IS ON SCREEN
PRESS PAR UNTIL RANGE IS ON SCREEN
USE FN△ / FN▽ SET TO 10V
PRESS PAR UNTIL DECPE IS DISPLAYED
USE FN△ / FN▽ TO SET TO SET TO 0.000
PRESS PAR UNTIL STYLE IS ON SCREEN
USE FN△ / FN▽ UNTIL APLY IS ON SCREEN
PRESS PAR UNTIL INP1 IS ON SCREEN
MOVE SAW TO LOWEST SETTING POSSIBLE
PRESS PAR UNTIL DSP1 IS ON SCREEN
USE FN△ / FN▽ UNTIL SCREEN READS SAME AS BLADE HEIGHT
PRESS PAR UNTIL INP2 IS ON SCREEN
MOVE SAW TO HIGHEST POSSIBLE POSITION
PRESS PAR UNTIL DSP2 IS ON SCREEN
USE FN△ / FN UNTIL SCREEN READS SAME AS BLADE HEIGHT
PRESS PAR
USE FN△ / FN▽ UNTIL 3-LOC IS DISPLAYED
PRESS PAR UNTIL CODE IS ON SCREEN
USE FN△ / FN▽ UNTIL 33 IS ON SCREEN
PRESS PAR THEN DSP

TO GET BACK INTO DISPLAY PROGRAMMING YOU MUST ENTER
IN CODE 33 TO PROGRAM.

BAKER PRODUCTS
BLADE HEIGHT
PROGRAMMING
INSTRUCTIONS