

# 4-SIDE PLANER

INSTRUCTION MANUAL

AND PARTS LIST

MODEL: M-412/410

KEEP THIS MANUAL FOR FUTURE REFERENCE



# SAFETY RULES

Woodworking can be dangerous if safe and proper operating procedures are not followed. However, if the operator thoroughly follow the related safety rules, and operate the machine correctly, the woodworking operation will be safe. As with all machinery and equipment, there are certain hazards involved with the operation of the machine. Operating the machine with respect and caution, and always pay attention to all warnings and safety rules will considerably lessen the possibility of damage to personal and machinery. However, if normal safety precautions are overlooked or ignored, a personal injury or machine damage may occur when operating the machine or a special condition occurs.

In order to minimize the possibility of personal injury, proper safety equipment are required, such as push sticks, proper clothes, wear goggles, dust masks, and hearing protection when operating the machine. Do not neglect any detail in safety protection, because even the best guard will not make up for poor judgment, careless mess or in attention.

Always use common sense and exercise caution in the workshop. If you have any question regarding the machine operation, do not try to operate the machine. Figure out an alternative procedure that is safer. **REMEMBER!**Your personal safety is your responsibility.

This machine was designed for certain applications only. C.K.M. Company strongly recommends that this machine not be modified and/or used for any application other than that for which it was designed. This will avoid any danger to the operator. Before operating the machine, the operator must thoroughly read this operation manual, and understand the machine applications, operation, and prohibited items and other possible danger, keep this operation manual for future reference. During operation, if you have any question, stop the machine and consult the operation manual, your local distributor or the machine manufacturer C.K.M. Company. This will not only avoid any accident occurring, while extending the machine service life.

## CHENG KUANG WOOD MACHINERY WORKS CO., LTD.

NO.6-10,ShenChin Rd., ChingShuiDist, Taichung, 43641, Taiwan, R.O.C.

TEL: 886-4-2620 1763 FAX: 886-4-2620 3763

[Http://www.ckmtw.com.tw](http://www.ckmtw.com.tw) E-mail: [ckmmail@ckmtw.com.tw](mailto:ckmmail@ckmtw.com.tw)