

PRESS PAR AND SCREEN WILL DISPLAY CODE
PRESS F1 UNTIL THE NUMBER 33 APPEARS ON THE SCREEN, THEN PRESS PAR
PRESS F1 UNTIL YOU SEE 4-SEC ON THE SCREEN, THEN PRESS PAR
PRESS PAR UNTIL YOU SEE OFFST ON THE SCREEN
PRESS F1 TO INCREASE THE CURRENT OFFSET OR F2 TO DECREASE THE CURRENT OFFSET
AFTER THE DESIRED OFFSET HAS BEEN SELECTED, PRESS PAR AND THEN PRESS DSP
YOU SHOULD NOW SEE THE NEW BLADE HEIGHT ADJUSTED FOR THE OFFSET THAT WAS CHANGED
IF CURRENT NUMBER IS STILL WRONG REPEAT THE PROCESS UNTIL YOU REACH THE CORRECT
BLADE HEIGHT. OFFSET ADJUSTMENT SHOULD ONLY BE USE FOR MINER ADJUSTMENTS PREFERABLY
1 INCH OR LESS. MORE THAN 1 INCH REFER TO THE BLADE HEIGHT CALIBRATION INSTRUCTIONS.



BAKER PRODUCTS
BLADE HEIGHT
OFFSET INSTRUCTIONS